

Katalog náhradních dílů pro
průmyslový šicí stroj

GARUDAN®

GF-130-543 H/L40



ANITA B s.r.o.

Hliníky 2068

680 01 Boskovice

Czech Republic


fax: +420 516 452 751

tel: +420 516 454 774,

+420 516 453 496

e-mail: info@anita.cz


A: BODY AND ITS ACCESSORIES



A: BODY AND ITS ACCESSORIES


No.	Ref. No.	Description	Pcs.
A1	H9601001	Arm	1
A2	H9601002	Bed	1
A3	H9601003	Oil pipe	1
A4	H9601004	Oil wick	3
A5	H9601005	Rubber plug	2
A6	H9601006	Needle bar guide bracket stud bushing	1
A7	H9601007	Set Screw	1
A8	H9601008	Set Screw	1
A9	H9601009	Presser bar bushing	1
A10	H9601010	Set Screw	1
A11	H9601011	Pin	1
A12	H9601012	Set Screw	1
A13	H9601013	Mandril of needle bar guide bracket	1
A14	H9601014	Set Screw	1
A15	H9601015	Arm side cover	1
A16	H9601016	Screw	1
A17	H9601017	Face plate	1
A18	H9601018	Screw	2
A19	H9601019	Thread guide	1
A20	H9601020	Screw	1
A21	H9601021	Nut	1
A22	H9601022	Tension spring	1
A23	H9601023	Tension disc	2
A24	H9601024	Tension screw stud	1
A25	H9601025	Tension nut	1
A26	H9601026	Thread tension regulator complete base	1
A27	H9601027	Screw	2
A28	H9601028	Tension releasing disc	1
A29	H9601029	Screw	1
A30	H9601030	Thread guide	1
A31	H9601031	Tension nut	1
A32	H9601032	Tension spring	1
A33	H9601033	Washer	2
A34	H9601034	Felt	2
A35	H9601035	Damping plate	1
A36	H9601036	Tension screw stud	1
A37	H9601037	Nut	1
A38	H9601038	Thread take-up spring	1
A39	H9601039	Spring	1
A40	H9601040	Thread take-up spring guide plate	1
A41	H9601041	Screw	1

A: BODY AND ITS ACCESSORIES



A42	H9601042	Screw	1
A43	H9601043	Nut	1
A44	H9601044	Tension spring	1
A45	H9601045	Tension disc	1
A46	H9601046	Thread tension regulator complete base	1
A47	H9601047	Screw	1
A48	H9601048	Thread guide	1
A49	H9601049	Screw	1
A50	H9601050	Rubber plug	1


B: NEEDLE BAR AND THREAD TAKE-UP MECHANISM



B: NEEDLE BAR AND THREAD TAKE-UP MECHANISM

No.	Ref. No.	Description	Pcs.
B1	H9602001	Pulley	1
B2	H9602002	Screw	1
B3	H9602003	Screw	1
B4	H9602004	Arm shaft	1
B5	H9602005	Collar	1
B6	H9602006	Set Screw	2
B7	H9602007	Thread take-up cam	1
B8	H9602008	Needle bar connecting base link screw	1
B9	H9602009	Screw	2
B10	H9602010	Set Screw	2
B11	H9602011	Pin	1
B12	H9602012	Thread take-up lever	1
B13	H9602013	Screw	1
B14	H9602014	Roller	1
B15	H9602015	Roller pin	1
B16	H9602016	Nut	1
B17	H9602017	Retaining ring-E type	1
B18	H9602018	Needle bar connecting link screw	1
B19	H9602019	Nut	1
B20	H9602020	Needle bar connecting link	1
B21	H9602021	Needle bar connecting stud	1
B22	H9602022	Set Screw	2
B23	H9602023	Needle bar	1
B24	H9602024	Screw	1
B25	H9602025	Needle	1
B26	H9602026	Needle bar guide bracket	1
B27	H9602027	Needle bar guide bracket pin	1
B28	H9602028	Oil wick	1
B29	H9602029	Needle bar guide bracket plate	1
B30	H9602030	Screw	1
B31	H9602031	Screw	1
B32	H9602032	Needle bar guide bracket plate base	1
B33	H9602033	Screw	1
B34	H9602034	Bushing	1
B35	H9602035	Set Screw	1
B36	H9602036	Felt	3
B37	H9602037	Bushing	1
B38	H9602038	Set Screw	1
B39	H9602039	Bushing	1
B40	H9602040	Set Screw	1


C: LOWER SHAFT MECHANISM



C: LOWER SHAFT MECHANISM

No.	Ref. No.	Description	Pcs.
C1	H9603001	Eccentric	1
C2	H9603002	Set screw	1
C3	H9603003	Pin	2
C4	H9603004	Screw	2
C5	H9603005	Washer	2
C6	H9603006	Bearing	1
C7	H9603007	Eccentric cover	1
C8	H9603008	Screw	2
C9	H9603009	Crank connecting rod	1
C10	H9603010	Crank connecting rod pin	1
C11	H9603011	Pin	1
C12	H9603012	Screw	1
C13	H9603013	Shuttle shaft	1
C14	H9603014	Plate	1
C15	H9603015	Plate	1
C16	H9603016	Screw	2
C17	H9603017	Nut	2
C18	H9603018	Inside shaft	1
C19	H9603019	Oil wick	1
C20	H9603020	Rivet	1
C21	H9603021	Lower shaft crank	1
C22	H9603022	Screw	1
C23	H9603023	Shuttle shaft slide block	1
C24	H9603024	Screw	1
C25	H9603025	Nut	1
C26	H9603026	Lower shaft	1
C27	H9603027	Collar	1
C28	H9603028	Set screw	2
C29	H9603029	Shuttle driver	1
C30	H9603030	Pin	1
C31	H9603031	Bobbin	1
C32	H9603032	Shuttle hook base	1
C33	H9603033	Felt	1
C34	H9603034	Screw	1
C35	H9603035	Shuttle race body	1
C36	H9603036	Screw	2
C37	H9603037	Spring	2
C38	H9603038	Shuttle race cap	1
C39	H9603039	Bushing	1
C40	H9603040	Set screw	1
C41	H9603041	Set screw	1


D: FEEDING MECHANISM



D: FEEDING MECHANISM

No.	Ref. No.°	Description	Pcs.
D1	H9604001	Feed cam	1
D2	H9604002	Set screw	2
D3	H9604003	Feed cam cover	1
D4	H9604004	Screw	2
D5	H9604005	Feed forked connection	1
D6	H9604006	Feed forked connection crank pin	1
D7	H9604007	Nut	1
D8	H9604008	Stitch length connecting link	1
D9	H9604009	Stitch length connecting link crank pin	1
D10	H9604010	Screw	1
D11	H9604011	Stitch length adjusting pin	1
D12	H9604012	Spring	1
D13	H9604013	Screw bar	1
D14	H9604014	Nut	1
D15	H9604015	Hook	1
D16	H9604016	Damping plate	1
D17	H9604017	Screw	2
D18	H9604018	Spacer	1
D19	H9604019	Screw	1
D20	H9604020	Stitch length adjusting bolt	1
D21	H9604021	Stitch length limited plate	1
D22	H9604022	Nut	1
D23	H9604023	Metal ball	1
D24	H9604024	Spring	1
D25	H9604025	Plastic ball	1
D26	H9604026	Nut	1
D27	H9604027	Feed driving rock shaft crank	1
D28	H9604028	Screw	2
D29	H9604029	Screw	1
D30	H9604030	Nut	1
D31	H9604031	Collar	1
D32	H9604032	Set screw	1
D33	H9604033	Crank pin	2
D34	H9604034	Feed dog base	1
D35	H9604035	Crank shaft	1
D36	H9604036	Oil wick	1
D37	H9604037	Screw	1
D38	H9604038	Collar	1
D39	H9604039	Screw	2
D40	H9604040	Crank	1
D41	H9604041	Screw	2


E: PRESSER FOOT MECHANISM



E: PRESSER FOOT MECHANISM

No.	Ref. No.	Description	Pcs.
E1	H9605001	Presser foot	1
E2	H9605002	Screw	1
E3	H9605003	Nut	1
E4	H9605004	Finger guard	1
E5	H9605005	Presser bar	1
E6	H9605006	Presser bar spring	1
E7	H9605007	Thumb screw	1
E8	H9605008	Nut	1
E9	H9605009	Walking foot	1
E10	H9605010	Screw	1
E11	H9605011	Presser bar	1
E12	H9605012	Screw	1
E13	H9605013	Presser bar lifting shaft	1
E14	H9605014	Washer	1
E15	H9605015	Collar	1
E16	H9605016	Set screw	2
E17	H9605017	Bolt	1
E18	H9605018	Plastic ball	1
E19	H9605019	Presser bar guide bracket	1
E20	H9605020	Connecting rod	1
E21	H9605021	Screw	1
E22	H9605022	Pin	1


F: PRESSER FPPT LIFTING SHAFT MECHANISM



F: PRESSER FOOT LIFTING SHAFT MECHANISM

No.	Ref. No.	Description	Pcs.
F1	H9606001	Presser foot lifting eccentric	1
F2	H9606002	Set screw	2
F3	H9606003	Eccentric connecting link	1
F4	H9606004	Screw	1
F5	H9606005	Washer	1
F6	H9606006	Nut	1
F7	H9606007	Adjusting crank	1
F8	H9606008	Screw	1
F9	H9606009	Presser foot lifting shaft	1
F10	H9606010	Presser foot lifting shaft crank	1
F11	H9606011	Screw	1
F12	H9606012	Presser foot lifting connecting link	1
F13	H9606013	Screw	2
F14	H9606014	Retaining ring-E type	4
F15	H9606015	Presser foot lifting lever	1
F16	H9606016	Screw	2
F17	H9606017	Presser foot lifting lever base	1
F18	H9606018	Screw	2
F19	H9606019	Roller	1
F20	H9606020	Bearing	1
F21	H9606021	Screw	1
F22	H9606022	Roller base plate	1
F23	H9606023	Screw	2
F24	H9606024	Walking foot lifting connecting link	1
F25	H9606025	Bushing	1
F26	H9606026	Set screw	1
F27	H9606027	Bushing	1
F28	H9606028	Set screw	1


G: NEEDLE BAR ROCK SHAFT MECHANISM



G: NEEDLE BAR ROCK SHAFT MECHANISM

No.	Ref. No.	Description	Pcs.
G1	H9607001	Needle bar rocking connecting link	1
G2	H9607002	Adjusting crank	1
G3	H9607003	Screw	1
G4	H9607004	Screw	1
G5	H9607005	Washer	1
G6	H9607006	Nut	1
G7	H9607007	Screw	1
G8	H9607008	Nut	1
G9	H9607009	Adjusting crank	1
G10	H9607010	Screw	1
G11	H9607011	Needle bar rock shaft	1
G12	H9607012	Collar	2
G13	H9607013	Set screw	4
G14	H9607014	Needle bar rocking crank	1
G15	H9607015	Set screw	1
G16	H9607016	Screw	1
G17	H9607017	Needle bar rocking connecting link	1
G18	H9607018	Screw	2
G19	H9607019	Retaining ring-E type	2
G20	H9607020	Screw base	1
G21	H9607021	Screw	3
G22	H9607022	Bushing	1
G23	H9607023	Set screw	1
G24	H9607024	Bushing	1
G25	H9607025	Set screw	1


H: KNEE LIFTER MECHANISM



H: KNEE LIFTER MECHANISM

No.	Ref. No.	Description	Pcs.
H1	H9608001	Knee lifter lever	2
H2	H9608002	Screw	1
H3	H9608003	Knee lifter lever base	1
H4	H9608004	Screw	2
H5	H9608005	Screw	1
H6	H9608006	Knee lifter rod	1
H7	H9608007	Screw	2
H8	H9608008	Coil spring	1
H9	H9608009	Screw	1
H10	H9608010	Screw	1
H11	H9608011	Washer	1
H12	H9608012	Knee lifter lever connecting plate	2
H13	H9608013	Screw	1
H14	H9608014	Screw	1

I: BOBBIN WINDER MECHANISM



I: BOBBIN WINDER MECHANISM

No.	Ref. No.	Description	Pcs.
I1	H9609001	Bobbin winder plate	1
I2	H9609002	Pin	1
I3	H9609003	Pin	1
I4	H9609004	Bobbin winder crank shaft	1
I5	H9609005	Bobbin winder crank shaft	1
I6	H9609006	Bushing.	2
I7	H9609007	Pin	1
I8	H9609008	Bobbin winder spring	1
I9	H9609009	Retaining ring-E type	2
I10	H9609010	Bobbin winder shaft	1
I11	H9609011	Bobbin base	1
I12	H9609012	Driven wheel	1
I13	H9609013	Friction rubber band	1
I14	H9609014	Bobbin winder lever	1
I15	H9609015	Screw	1
I16	H9609016	Winding length limited plate	1
I17	H9609017	Screw	1
I18	H9609018	Washer	1
I19	H9609019	Pin	1
I20	H9609020	Set screw	1
I21	H9609021	Set screw	2
I22	H9609022	Spring	1
I23	H9609023	Bobbin winder cam	1
I24	H9609024	Driving Wheel	1
I25	H9609025	Set screw	2
I26	H9609026	Screw	3
I27	H9609027	Screw	1
I28	H9609028	Tension disc	2
I29	H9609029	Nut	1
I30	H9609030	Limited plate	1
I31	H9609031	Spring	1
I32	H9609032	Thread guide	1
I33	H9609033	Washer	2
I34	H9609034	Blade	1
I35	H9609035	Screw	2

J: ACCESSORIES

